

Trekking Poles Accessories

Tip protector for added grip and noise/terrain scarring reduction on rock, hard-packed dirt and urban surfaces. Recommended for backpacking and trek/day hiking



Powder baskets for the deepest days of the season. Recommended for skiing/snowshoeing/touring in the snow. To install, remove tip protector and rotate the basket clockwise while firmly pushing it onto the pole tip until it spins freely and is rested against the collar of the pole tip. To remove, rotate the basket counterclockwise while firmly pulling towards the pole tip.

